

TECHNICAL BULLETIN

ARC SPRAY WIRE SPOOL COVERS


(MTI Part Nos. 5000070 and 5000071)

Miller Thermal has wire spool covers for use with its arc spray systems.

Wire spool covers resist dust, moisture and other contaminants to promote safer, smoother wire feeding. Drive rolls and wire lines require less maintenance with wire spool covers in place. Wire spool covers are ideal for infrequently used feeder systems. The body has a window to view wire level remaining on spool and a hole through which wire is routed to the feeder.

Install wire spool covers by first removing all spool support parts. A list and diagram of spool support parts is in Section 7 of the BP400 Operator's Manual. Install wire spool cover body and then replace all spool support parts. Install wire spool and align wire for spraying. Place cover on spool body. The cover easily snaps on and off when changing spools.

Wire spool covers are sold separately from arc spray systems. The left spool cover is P/N 5000070. The right spool cover is P/N 5000071.



Arc Spray Wire Spool Covers